



**Connection diagram for product 59160 HF Parrot Mazda > 2001**



- 1 + left front
- 2 - left front
- 3 + right front
- 4 - right front
- 5 +left rear
- 6 - left rear
- 7 + right rear
- 8 - right rear
- 9 antenna remote
- 10-13 common wires
- 14 + 12V permanent
- 15 illumination
- 16-21 common wires
- 22 +12V power
- 23 mute
- 24 Ground

- 1 - right rear
- 2 + right rear
- 3 - left rear
- 4 +left rear
- 5-8 common wires
- 9 antenna remote
- 10 - right front
- 11 + right front
- 12 - left front
- 13 + left front
- 14 Ground
- 15 mute
- 16 +12V power
- 17-22 common wires
- 23 illumination
- 24 + 12V permanent